

Unlock 코드를 사용하여 게이트웨이 포인팅 주소를 monnit Server에서
고객사 3rd Party Server(지정 호스트 또는 IP)로 변경할수 있습니다.
게이트웨이 1개당 1개의 unlock 코드가 최초1회 필요합니다.

- <https://www.imonnit.com/point> 사이트에 들어가서
- ID와 SC를 게이트웨이 하단의 스티커를 활용하여 입력합니다.
- 그 뒤 페이지에서 게이트웨이 연락 코드를 입력하시고 락을 해제합니다.
- 연락 후 호스트 어드레스와 포트 넘버를 입력해 주시면 원하시는 주소 및 ip로 데이 터 전송을 합니다.

The image shows two screenshots of the Monnit online wireless sensors portal. The top screenshot is the 'Enter Gateway Information' page, which prompts the user to enter their Gateway ID and Checkcode. The Gateway ID is 945455 and the Gateway Code is imfoiy. A blue arrow points to a 'Gateway Back Label' sticker on the right, which contains FCC ID ZTL-RFSC1 and IC 9794A-RFBC1, along with a barcode and ID/Code fields. The bottom screenshot is the 'Edit Gateway Server Settings' page, which shows the last check-in date as 10/11/2019 1:04 AM, the Enterprise/Express Host Address as sensorgateway.com, and the Enterprise/Express Port Number as 3000. Both screenshots include navigation links for Network Overview, Account Information, and Legal, and a footer with copyright information for Monnit, Inc. © 2009-2019.